



CANOPY TENTS

ONE CHOICE - 10 FT. CANOPY
 PRODUCT CODE: OC-CASTL-CST10

Step 1
 Take your frame and slightly expand it to expose the corner bars.




Step 2
 Take your canopy graphic and place it on top of the frame.



Step 3
 Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of Hook and Loop sewn to it.



Step 4
 With the canopy securely in position, expand the frame until the corner latches lock into place.



Step 5
 Increase the height by extending the lower legs.



Step 6
 Pull each leg down until the latch locks into place.



Step 7
 Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole.



Step 8
 The dome cap will push out the canopy, creating tension to flush out any loose areas.



Step 9
 The install is complete.

